# Xtensys



## Features and Benefits

- The distance from the computers to the Xtensys unit and from the unit to the user station can be up to 1,000 feet using standard CATx cabling.
- Auto equalization and skew compensation for a perfect display using CAT5, 5e, 6, or 7 cable.
- Multi-platform support PS/2, USB, Sun, Unix, Mac, or serial devices.
- Each computer port can be configured for connection to a computer or serial device.
- Advanced security for configuration and access
- Configuration and access through advanced OSD
- Remote access over CATx cable
- Extremely modular architecture for easy connection from multiple user stations.
- Switch models available with:
  - 0, 2, 4, 8, 12 or 16 users and
  - 4, 8, 16, 32, 48, or 64 CPU ports
- User station models available with:
  - 1 KVM connection and 1 RJ45 link
  - 1 KVM connection and 4 RJ45 links
- Local port for quick access to the switch
- Rack mount kits available for a 19" rack
- Lifetime free flash upgrades
- Designed and manufactured in USA

### CAT5 KVM Switch

Extend the distance from the computers to the user stations up to 1,000 feet using CATx cabling Configure any port for CATx or serial devices

Modular architecture and built-in high performance video bus.

Auto equalization and skew on UTP cable for video up to 1920  $\times$  1440

Connect a user station to multiple Xtensys units

Models available for 0 - 16 users and 1 - 64 CPUs

Space saving Micro-Mini KVM Transmitter

Advanced security features

## The Xtensys<sup>™</sup> Advantage . . .

Leave it to Rose to come up with such a feature packed product. The Xtensys CAT5 KVM switch features the latest in technology and can be deployed and scaled to any computer environment from the simplest to the most complex.

You can connect either a miniature Rose KVM transmitter or a serial cable to the RJ45 computer input connectors on the unit. It auto-detects the interface. If video is present it will automatically measure the distance and equalize the video for maximum clarity.

At the user side you connect a KVM user station to access any computer. The built in OSD and hot-key system allows you to select a computer using simple keyboard commands or from a sortable list and switch to it instantly.

The XTR-11 user station connects a single KVM station to a single KVM port on an Xtensys switch. For the ultimate in connection flexibility, the XTR-14 user station permits a single KVM station to connect to a KVM port on four different Xtensys switches, four standalone servers/computers, or a combination of Xtensys switches and standalone computers/servers.


As the inventors of the KVM switch, Rose continues to provide leading solutions for your server management needs. With headquarters in the US and offices in



Direct connect CAT5 Transmitter streamlines your installation

Europe and Asia, Rose provides a full range of capabilities and support. Call us today for more information about this and other Rose products.

## **Typical Application**



**Cables...** All cabling to the user stations and computers uses standard CATx cable. Max cumulative cable length of 1,000'

**Installation...** Xtensys is easy to install and configure. For a single unit installation, you simply connect your computers to the CPU ports; connect the KVM consoles to the user stations, connect the user stations to the Xtensys switch and it's ready for operation. If access to additional computers is needed, up to 4 units can be accessed from a single user station. This provides access to as many as 256 computers. In addition to being able to access multiple units, each unit's CPU port can be connected to a serial device and controlled from any user station. The 0, 2, 4, and 8 user models are 1U high, the 12 and 16 user models are 2U high.

Security... The security system allows you to customize access to the unit and to the connected computers. The system administrator has security privileges for the complete system. He assigns passwords and access rights for all users. The administrator can perform security functions for a single unit. Users can be assigned a password and must login to obtain access to the computers.

**Operation...** From each user console, you can access any connected computer by simple keyboard commands or use an on-screen list of the computers to access. When connected, the user can fully utilize all applications and features of the connected computer.

Keyboard and Mouse... Xtensys fully emulates the keyboard and mouse, so computers can be booted at any time. A "Keep Alive" feature ensures that the keyboard and mouse will function properly even if the switch temporarily loses power.

**On-Screen display...** The on-screen display is a menu-driven display for configuring the unit, setting up security access, and for quick and easy access to the connected computers. You use the keyboard to highlight a feature on the OSD and press enter to use that feature.

**Firmware update...** The firmware upgrade utility is a windows based program that provides an automated process for upgrading the unit's firmware. New firmware upgrades are available from our web site.

#### Part Numbers Xtensys Switch

XTS-VaXbDc-L

a = Remote Users (0, 2, 4, 8, 12,16) (0 = 0 remote users, 1 local user) b = CPUs (4, 8, 16, 32, 48, 64) c = Controller Cards (2, 4, 8, 12, 16) -L = Local PS2 KVM ports (Standard) -LU = Local PS2+USB KVM ports (Optional)

#### User KVM Stations XTR-11

XTR-11	1X1 User KVM Station (VGA-PS/2)
XTR-11-U	1X1 User KVM Station (VGA-USB/PS/2)
XTR-14	1X4 User KVM Station (VGA-PS/2)
XTR-14-U	1X4 User KVM Station (VGA-USB/PS/2)
TFR-05D500FSUB-2.1	Universal power adapter (110-240V-5V)

#### CATx Transmitters

XTT-MP	
XTT-MP2	
XTT-MU	
XTT-MPU	

#### UTP Transmitter (VGA/PS/2) UTP Transmitter (VGA/PS2/2-RJ45) UTP Transmitter (VGA/USB) UTP Transmitter (VGA/PS2 & USB)

1U switch (X8, X16, X32)

2U switch (X48, X64)

**User Station** 

#### Rack Mount Brackets

RM-UB19	
RM-UC19	
RM-UM19	

#### Specifications

Dimensions	Width	Depth	Height
1U Model	17"/43.2 cm	6.75″/17.1 cm	1.75"/4.4 cm
2U Model	17"/43.2 cm	6.75″/17.1 cm	3.5"/8.9 cm
User Station	8.75"/22.2 cm	5.65"/ 36.4 cm	1.75"/4.4 cm
CATx Transmitter	1.3"/3.3cm	1.65"/4.2cm	0.63"/1.6cm

#### Weight

 $\begin{array}{l} \mbox{Xtensys 6-9.9 lbs} / 2.7 - 4.5 \ \mbox{kg} \\ \mbox{User station 2-3 lbs} / 0.9 - 1.4 \ \mbox{kg} \end{array}$ 

#### **Power Consumption**

	Input Voltage	Watts		
1U Model	100-120/200-240V	60W		
2U Model	100-120/200-240V	140W		
User Station	100-240V	20W		
CATx Transmitter	100-240V	12.5W		
Resolution	Up to 1920 x 1440			
Environmental Connectors	0 – 50° C, 0% – 80% non-condensing R.H. Power: IEC 320 standard receptacle CPU/Remote: KVM: RJ45 Local KVM: MD6, HD15, USB			
Keyboard / Mouse	Expansion: RJ45 PS/2, Sun, USB (PC, Sun, Mac)			
Chassis	Metal			
Scan Interval	0 – 255 seconds			
Indicators	On-Line / selected LEDs / Power			
Switches	IEC 320 Power			
Xtensys Version K500h Main menu Configure	Copyright 1950-2005			



Easy to use OSD for configuration

## 株式会社サイバネテック

〒104-0028 東京都中央区八重洲2-11-4 TEL:03-3272-8503 FAX:03-3274-9550 https ://www.cybernetech.co.jp